



EW80 *des ready-to-use solution*

Disinfect like the pros

EW80 *des ready-to-use solution* is a compound for the disinfection of technical equipment made of metal, plastic, rubber, neoprene, etc.

Applications:

Breathing regulators, mouthpieces, jackets, suits, respirators, protective suits, gloves, hoses, medical equipment and other sensitive materials become completely disinfected after having been cleaned with the EW80 *des ready-to-use solution*.

Ecology

EW80 *des ready-to-use solution* has been designed from the standpoint of environmental impact: No phenol, chlorine, aldehyde nor alcohol are used.

Modern substances, in combination with a synergistic adjuvant system already in lowest concentration, prove highly effective.

EW80 *des ready-to-use solution* is produced according to GMP guidelines and is subject to continuous laboratory quality control.

Easy to use

EW80 *des ready-to-use solution can be used immediately*: Sprinkle the several devices or objects completely with the solution. After 5 minutes the self-reliant disinfection will be completed. The disinfected parts should then be thoroughly rinsed in clear water and hung to dry: disinfection is done!



Scientifically proven

The concentrate of *EW80 des ready-to-use solution* has been inspected according to VAH (DGHM) criteria by two independent hygiene professors in their institutions and included in this list because of its disinfecting effect. These reports demonstrate the extensive disinfection of the *EW80 des*. The user is on the hygienically safe side. The concentrate of *EW80 des ready-to-use solution* has been tested for material compatibility and declared safe by the DEKRA-EXAM (formerly DMT). The valuable equipment will therefore not be affected!

Composition and microbiology

100g of *EW80 des concentrate* contain:

16,0 g Dimethylbenzylcocosfettalkylammoniumchlorid

EW80 des ready-to-use solution is bactericidal, fungicidal and virus inactivating (HBV / HIV, Rota, Tb). Appearance of the concentrate: blue, clear liquid.

Special Considerations

Do not ingest, avoid skin and eye contact. Rinse wetted parts of the body with plenty of water. Gloves must be worn whilst working with disinfectants in accordance with the accident prevention regulations of the professional association. Use biocides safely. Always read the label and product information before use.



Special instructions related to the concentrate - Biocides Directive / CLP - Reg.:

Use biocides safely. Always read the label and product information before use.

Precautionary statements related to the concentrate:

Wear protective gloves/protective clothing/eye protection/face protection

If swallowed: Rinse mouth. Do NOT induce vomiting

If on skin (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower

If In eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

If exposed: Call a POISON CENTER or doctor/physician.

Hazard Statements related to the concentrate:

H314 Causes severe skin burns and eye damage

H400 Very toxic to aquatic life

H411 Toxic to aquatic life with long lasting effects

For further information, please refer to the Safety Data Sheet.
