

Recommendations for product switches
for machine disinfection of PPE with ,EW80 *mat*'
to avoid the „chemical cocktail“:

- ⇒ With a thorough wash and 1% ,EW80 *clean*' in the washing machine or the cleaning and disinfection machine, rinse out the remains of the old product. Take special care that the so-called "sump" in the machine is completely removed.
- ⇒ Carefully rinse with clear water in two rinse cycles.
- ⇒ Clean all product-carrying parts such as hoses, suction lances, dosing points with 1% ,EW80 *clean*' and then rinse with clear water.
- ⇒ Wash textile protective bags for example for respirator masks, in one wash cycle with ,EW80 *clean*' and then rinse with clear water in at least two wash cycles.
- ⇒ For manual treatment, place the masks in water at 30 - 40°C and 2% ,EW80 *clean*' for approx. 1-2 hours and then wash thoroughly. Replace glued or damaged valves or valve-discs.
- ⇒ Dispose or remove the old product out of the washroom and point out the new product ,EW80 *mat*'.